


JBH



JBH Programmer User Manual

Operation Guide

The programmer is connected to the interface of the joystick, and the programmer automatically starts up. The startup interface is as follows.



Then click the page down button to enter the parameter modification interface.

Parameter 1

Parameter 1: Motor type
This parameter cannot be modified.
The parameter information is read from the driver.
The number 8 represents an 8-inch motor. Similarly,
there are 10-inch and 12-inch motors.

1 Motor Type

This a JBH Fatory Seting
DO NOT CHANGE THIS SETTING.
Motor Type.
Motor Types include 8 inches,
10 inches,12 inches.
Defaults: 08
Current Value: 08
RANGE SETTING: 8 to 12

Pg dn Enter **08**


Operation Guide

Parameter 2

Parameter 2: Forward Direction

This parameter cannot be modified.

The parameter information is read from the drive.
1 represents the current running direction, and 0
represents the reverse direction.



Parameter 3

Parameter 3: Turn Direction

This parameter cannot be modified.


The parameter information is read from the driver.
1 represents the current running direction, and 0
represents the reverse direction.



Parameter 4

Parameter 4: Turn Max speed, unit is KM/H.


Press the plus or minus button to modify the speed. Press Enter to set this parameter. Current Value will show identical value as set parameter. The parameter range is 0.5 to 3.



Operation Guide


Parameter 5

Parameter 5: Forward Max speed, unit is KM/H.
Press the plus or minus button to adjust this parameter. Press Enter to set this parameter.
Current Value will show identical value as set parameter. The parameter range is from 2 to 6.5.




Parameter 6

Parameter 6: Reverse Max speed, unit is KM/H.
Press the plus or minus button to adjust this parameter. Press Enter to set this parameter.
Current Value will show identical value as set parameter. The parameter range is from 0.5 to 4.



Parameter 7

Parameter 7: Forward brake coefficient
Press the plus or minus button to adjust this parameter. The larger the value, the shorter the braking distance. Press the Enter key to set this parameter. Current Value will show identical value as set parameter. The parameter range is 10 to 18.




Operation Guide

Parameter 8

Parameter 8: Turn brake coefficient

Press the plus or minus buttons  to adjust this parameter. The larger the value, the shorter the braking distance. Press the Enter key  to set this parameter. Current Value will show identical value as set parameter. The parameter range is 4 to 12.



Parameter 9

Parameter 9: Forward Acceleration


Press the plus or minus buttons  to adjust this parameter. The larger the value, the slower the acceleration. Press the Enter key  to set this parameter. Current Value will show identical value as set parameter. The parameter range is 10 to 60.



Parameter 10

Parameter 10: Forward Deceleration

Press the plus or minus button  to adjust this parameter. The larger the value, the faster the deceleration. Press the Enter key  to set this parameter. Current Value will show identical value as set parameter. The parameter range is 3 to 7.




Operation Guide

Parameter 11

Parameter 11: Backward Acceleration


press the plus or minus button to adjust this parameter. The larger the value, the slower the acceleration. Press the Enter key to set this parameter. Current Value will show identical value as set parameter. The parameter range is 10 to 60.



Parameter 12

Parameter 12: Reverse Deceleration


press the plus or minus button to adjust this parameter. The larger the value, the faster the deceleration. Press the Enter key to set this parameter. Current Value will show identical value as set parameter. The parameter range is 3 to 7.



Parameter 13

Parameter 13: Turn Acceleration

Press the plus or minus buttons to adjust this parameter. The larger the value, the slower the acceleration. Press the Enter key to set this parameter. Current Value will show identical value as set parameter. The parameter range is 15 to 50.




Operation Guide

Parameter 14

Parameter 14: Turn Deceleration


Press the plus or minus buttons  to adjust this parameter. The larger the value, the faster the deceleration. Press the Enter key  to set this parameter. Current Value will show identical value as set parameter. The parameter range is 3 to 7.



Parameter 15

Parameter 15: Brake voltage.


This parameter comes from the driver and cannot be adjusted. The parameter range is 9 to 24.



Parameter 16

Parameter 16: Over voltage

This parameter comes from the driver and cannot be adjusted. The parameter range is 15 to 99.




Operation Guide

Parameter 17

Parameter 17: Undervoltage


This parameter comes from the driver and cannot be adjusted. The parameter range is 15 to 99.



Parameter 18

Parameter 18: Automatic Shutdown time

Press the plus or minus buttons to adjust this parameter. The larger the value, the longer the automatic shutdown time. Press the Enter key to set this parameter. Current Value will show identical value as set parameter. The parameter range is 5 to 60 minutes.



www.jbhmedical.com

Anhui JBH Medical Apparatus Co. Ltd.
No.116, Qicang Road, Mingguang, Anhui, 239400, China